

- E** Stage Exhaust Fan Switch
- B** Stage Bell & Red Light
- P** Stage Telephone
- H** House Lights
- A** Portable AC On/Off Power
- Evap Water
- Stage Sink or Water
- 208V-50A SINGLE PHASE
- 120V-20A SINGLE PHASE
- Stage Power Distro Panel
- MAIN STAGE POWER 3600 amp Cam Lock or Breaker Panel (as noted)
- FIRE SPRINKLER WATER MAIN
- FIRE ALARM CONTROL PANEL
- FIRE EXTINGUISHER
- Building / Stage Roof Support
- Cat Hole (Cable Pass Through)
- Ladder to Cat Walk

